








Modell	A1	A2	X1	X2	Y1	Y2	B1	B2	C1	C2	D	H
KDD 75Lx90R	750	900	740-750	890-900	721-731	871-881	520	620	211-221	261-271	775	1950
KDD 80Lx80R	800	800	790-800	790-800	771-781	771-781	520	520	261-271	261-271	740	1950
KDD 80Lx90R	800	900	790-800	890-900	771-781	871-881	520	620	261-271	261-271	805	1950
KDD 80Lx100R	800	1000	790-800	990-1000	771-781	971-981	520	620	261-271	361-371	805	1950
KDD 90Lx75R	900	750	890-900	740-750	871-881	721-731	620	520	261-271	211-221	775	1950
KDD 90Lx80R	900	800	890-900	790-800	871-881	771-781	620	520	261-271	261-271	805	1950
KDD 90Lx90R	900	900	890-900	890-900	871-881	871-881	620	620	261-271	261-271	880	1950
KDD 90Lx100R	900	1000	890-900	990-1000	871-881	971-981	620	620	261-271	361-371	880	1950
KDD 100Lx80R	1000	800	990-1000	790-800	971-981	771-781	620	520	361-371	261-271	805	1950
KDD 100Lx90R	1000	900	990-1000	890-900	971-981	871-881	620	620	361-371	261-271	880	1950
KDD 100Lx100R	1000	1000	990-1000	990-1000	971-981	971-981	620	620	361-371	361-371	880	1950

